

LESJÖFORS TECHNICAL

Global mind. Local heart.

Bulletin

No. 8

Front Coil Springs Mounting Instructions

Ford C-Max, Focus II | Mazda 3 | Volvo C30, C70 II, S40 II, V40 II, V50

When replacing front coil springs on the above vehicles, it is important to make sure the top spring plate is correctly lined up with the shock absorber.

After locating the top pin (see diagram), position the strut top mount so that the top pin aligns with the bottom pin.

Failure to align the top and bottom pins will cause the spring to bend and rub against the chassis.

